



Assembly instructions

Cut out the two items and stick to scrap cardboard such as breakfast cereal box.

Cut out the blade hole on both pieces

Drill a hole on the cross mark of an appropriate size for a pop rivet

Pop rivet the two pieces together